



# Installation Instructions

## AC (120/240V) Output Module

### Catalog Number 1771-OAN

#### To The Installer

This document provides information on:

To	See page
↓ Important User Information	1
↓ Environment and Enclosure	3
↓ Pre-installation Considerations	4
↓ Power Supply Requirements	4
↓ Initial Handling Procedures	5
↓ Key the Backplane Connector	5
↓ Install the Module and Field Wiring Arm	6
↓ Connect Wiring to the Module	7

For this reference information	See page
→ Status Indicators	10
→ Replacing Fuses	10
→ Specifications	11

#### Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of these products must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards. In no event will Rockwell Automation be responsible or liable for indirect or consequential damage resulting from the use or application of these products.

Any illustrations, charts, sample programs, and layout examples shown in this publication are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Rockwell Automation does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen–Bradley publication SGI–1.1, Safety Guidelines for Application, Installation, and Maintenance of Solid–State Control (available from your local Rockwell Automation office), describes some important differences between solid–state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this publication, notes may be used to make you aware of safety considerations. The following annotations and their accompanying statements help you to identify a potential hazard, avoid a potential hazard, and recognize the consequences of a potential hazard.

---

**WARNING**

Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

---

---

**ATTENTION**

Identifies information about practices or circumstances that may lead to personal injury or death, property damage, or economic loss.

---

---

**IMPORTANT**

---

Identifies information that is critical for successful application and understanding of the product.

---

**ATTENTION****Environment and Enclosure**

This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC publication 60664-1), at altitudes up to 2000 meters without derating.

This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR Publication 11. Without appropriate precautions, there may be potential difficulties ensuring electromagnetic compatibility in other environments due to conducted as well as radiated disturbance.

This equipment is supplied as “open type” equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present, and appropriately designed to prevent personal injury resulting from accessibility to live parts. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

See NEMA Standards publication 250 and IEC publication 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosures. Also, see the appropriate sections in this publication, as well as the Allen-Bradley publication 1770-4.1, (“Industrial Automation Wiring and Grounding Guidelines”), for additional installation requirements pertaining to this equipment.

---

## Pre-installation Considerations

The 1771-OAN ac output module is a source output and requires a sink input. A sink input provides a path to ground and a source output provides a positive voltage path.

This module is not compatible with 2-slot addressing. You must use 1-slot addressing with restrictions, or 1/2-slot addressing with no restrictions.

### IMPORTANT

You must use this module in a 1771-A1B thru -A4B or later 1771 I/O chassis. Refer to the Table below for processor compatibility.

## Processor Compatibility Chart

System Type	Use with Processors:
Local	Mini-PLC-2/02 (cat. no. 1772-LZ, -LZP) Mini-PLC-2/16 (cat. no. 1772-LX, -LXP) Mini-PLC-2/17 (cat. no. 1772-LW, -LWP) PLC-5/15, Series B and later (cat. no. 1785-LT)
Remote (with a 1771-ASB remote I/O adapter)	PLC-2/20 (cat. no. 1772-LP2) PLC-2/30 (cat. no. 1772-LP3) PLC-3 (cat. no. 1775-L1, -L2, -L3, -L4) PLC-3/10 (cat. no. 1775-LP4, -LP8) PLC-5/15, Series B and later (cat. no. 1785-LT)

**Do not** place this module in the same I/O chassis as the 1771-IX thermocouple module. You can use this module in the same chassis as the 1771-IXE thermocouple module.

## Power Supply Requirements

The controller or I/O chassis power supply, connected through the backplane of the I/O chassis, powers the logic circuitry of the output modules. The maximum current drawn from this supply is 800mA.

## Initial Handling Procedures

### ATTENTION



### Preventing Electrostatic Discharge

This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wriststrap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- If available, use a static-safe workstation.
- When not in use, keep modules in appropriate static-safe packaging.

## Key the Backplane Connector

Place your module in any slot in the chassis except the leftmost slot which is reserved for processors or adapters.

### ATTENTION

Observe the following precautions when inserting or removing keys:


- insert or remove keys with your fingers
- make sure that key placement is correct

Incorrect keying or the use of a tool can result in damage to the backplane connector and possible system faults.



Position the keying bands in the backplane connectors to correspond to the key slots on the module.

Place the keying bands:  
between 16 and 18  
between 22 and 24



You can change the position of these bands if subsequent system design and rewiring makes insertion of a different type of module necessary.

11022-I


## Install the Module and Field Wiring Arm

### ATTENTION




Remove power from the 1771 I/O chassis backplane and field wiring arm before removing or installing an I/O module.

- Failure to remove power from the backplane or wiring arm could cause module damage, degradation of performance, or injury.
- Failure to remove power from the backplane could cause injury or equipment damage due to possible unexpected operation.



Snap the chassis latch over the top of the module to secure it.




Swing the chassis locking bar down into place to secure the modules. Make sure the locking pins engage.

19809

Attach the wiring arm (1771-WN) to the horizontal bar at the bottom of the I/O chassis.

The wiring arm pivots upward and connects with the module so you can install or remove the module without disconnecting the wires.



17643

## Connecting Wiring to the Module

You make connections to the module through the field wiring arm (cat. no. 1771-WN). The arm pivots on the I/O chassis to connect with terminals on the front of the module and acts as a terminal strip. The wiring arm allows the module to be removed from the chassis without disconnecting wiring.

---

### ATTENTION



Turn the power to the chassis off before connecting or disconnecting any wiring. Turn off power to the I/O chassis before inserting the module into the chassis.

- Failure to remove power from the backplane could cause module damage, degradation of performance, or injury.
  - Failure to remove power from the backplane could cause injury or equipment damage due to possible unexpected operation.
- 

1. Make certain all power is removed from the module before making wiring connections.
  2. Swing the wiring arm up into position on the front of the module. The locking tab on the module will secure it into place.
  3. Make your connections to the field wiring arm as shown in the connection diagram. (Use the label on the front of the wiring arm to identify your wiring.)
- 

### ATTENTION



The field wiring arm terminal identification number is not the same as the number of the bit which controls that output.

---

## I/O Module Groups

Each module condenses two full module groups (32 outputs) into each I/O chassis slot. For example:

- Module group 1 = outputs 00 through 17
- Module group 2 = outputs 00 through 17 (module group 2 represents the second set of outputs).


Terminals 1 through 20 represent module group 1. Terminals 21 through 40 represent module group 2. Terminals 1, 11, 21 and 31 are ac high (L1).

## **Connection Diagram for the 1771-OAN AC Output Module**

Note: Terminals on the left are even numbered (2 thru 40), and terminals on the right are odd numbered (1 thru 39).

Module group 1 = outputs 00 through 17  
Module group 2 = outputs 00 through 17  
(module group 2 represents the second set of outputs.)

Terminals 1 through 20 represent module group 1. Terminals 21 through 40 represent module group 2. Terminals 1, 11, 21 and 31 are ac high (L1).



**If multiple power supplies are used, do not exceed the specified isolation voltage.**

For operating voltages greater than 120V ac, each channel group must be connected to the same operating voltage phase at L1.

11852-1

**Table A**  
**Module Output Terminal Assignments**

Terminal Number	Output Assignment	I/O program address	Terminal Number	Output Assignment	I/O program address
01	<sup>1</sup> 120V ac	-	21	<sup>1</sup> 120V ac	-
02	Output 00	ORG00	22	Output 00	0R(G+1)00
03	Output 01	ORG01	23	Output 01	0R(G+1)01
04	Output 02	ORG02	24	Output 02	0R(G+1)02
05	Output 03	ORG03	25	Output 03	0R(G+1)03
06	Output 04	ORG04	26	Output 04	0R(G+1)04
07	Output 05	ORG05	27	Output 05	0R(G+1)05
08	Output 06	ORG06	28	Output 06	0R(G+1)06
09	Output 07	ORG07	29	Output 07	0R(G+1)07
10	N.C.	-	30	N.C.	-
11	<sup>1</sup> 120V ac	-	31	<sup>1</sup> 120V ac	-
12	Output 10	ORG10	32	Output 10	0R(G+1)10
13	Output 11	ORG11	33	Output 11	0R(G+1)11
14	Output 12	ORG12	34	Output 12	0R(G+1)12
15	Output 13	ORG13	35	Output 13	0R(G+1)13
16	Output 14	ORG14	36	Output 14	0R(G+1)14
17	Output 15	ORG15	37	Output 15	0R(G+1)15
18	Output 16	ORG16	38	Output 16	0R(G+1)16
19	Output 17	ORG17	39	Output 17	0R(G+1)17
20	N.C.	-	40	N.C.	-


Where:  
 R = rack number (1, 2, 3, etc.)  
 G = I/O group (0 - 7)  
 G+1 = I/O group plus 1

**Note:** If multiple power supplies are used, do not exceed the specified isolation voltage.

<sup>1</sup> For operating voltages greater than 120V ac, each channel group must be connected to the same operating voltage phase at L1.

## Interpreting the Status Indicators

The module has 32 status indicators on the module front plate. These represent the control status of the outputs. Each indicator is lit when its corresponding output is energized.



11853-I

## Replacing the Fuses

Each group of eight outputs share a common fuse. To replace a blown fuse, proceed as follows:



**ATTENTION**  
Remove power from the 1771 I/O chassis backplane and field wiring arm before removing or installing an I/O module.

- Failure to remove power from the backplane or wiring arm could cause module damage, degradation of performance, or injury.
- Failure to remove power from the backplane could cause injury or equipment damage due to possible unexpected operation.

1. Turn off power to the chassis.
2. Remove the module from the I/O chassis.
3. Remove the blown fuse from the fuse holder (accessible through the side cover), and replace it with a 4A, 250V normal blow fuse.
4. Reinsert the module into the I/O chassis.
5. Turn on power to the chassis.

**Specifications - ac (120-240V) Output Module, Cat. No. 1771-OAN**

Outputs per module	32 (4 groups of 8)	
Module Location	1771-A1B thru -A4B or later 1771 I/O Chassis	
Voltage Range	85 to 264V ac, 47-63Hz	
Nominal Voltage	120/240V ac	
Maximum Output Current	Per Point	1.0A at 30°C; Derate linearly to 0.3A at 60°C
	Per Group	2.0A at 30°C; Derate linearly to 0.6A at 60°C
	Per Module	8.0A at 30°C; Derate linearly to 2.4A at 60°C
Maximum Surge Current		10A for 25ms at 1s intervals at 30°C 10A for 25ms at 2s intervals at 60°C
Minimum Load Current		10mA per output <sup>2</sup>
Maximum On-state Voltage Drop		1.5V ac (rms) @ 1A
Maximum Off-state Leakage Current		2.3mA per output @ 230V ac, 60Hz 1.2mA per output @ 120V ac, 60Hz
Maximum Output Signal Delay	Off to On	1.0ms maximum
	On to Off	9.3ms @ 60Hz; 11.0ms @ 50Hz
Power Dissipation		16.2W (max); 1.0W (min)
Thermal Dissipation		55.4 BTU/hr (max); 3.4 BTU/hr (min)
Isolation Voltage		Tested to withstand 1000V for 60s
Backplane Current		800mA maximum @ 5V DC
Environmental Conditions		
Operational Temperature	IEC 60068-2-1 (Test Ad, Operating Cold) IEC 60068-2-2 (Test Bd, Operating Dry Heat) IEC 60068-2-14 (Test Nb, Operating Thermal Shock) 32 to 140°F (0 to 60°C)	
Storage Temperature	IEC 60068-2-1 (Test Ab, Unpackaged, Nonoperating Cold) IEC 60068-2-2 (Test Bb, Unpackaged, Nonoperating Dry Heat) IEC 60068-2-14 (Test Na, Unpackaged, Nonoperating Thermal Shock) -40 to 185°F (-40 to 85°C)	
Relative Humidity	IEC 60068-2-30 (Test Db, Unpackaged, Nonoperating Damp Heat) 5 to 95% noncondensing	
Shock	IEC 60068-2-27 (Test Ea, Unpackaged Shock)	
Operating	30g	
Nonoperating	50g	
Vibration	IEC 60068-2-6 (Test Fc, Operating) 2g @ 10-500Hz	
ESD Immunity	IEC 61000-4-2 4kV contact discharges	
Radiated RF Immunity	IEC 61000-4-3 10V/m with 1kHz sine-wave 80% AM from 30MHz to 1000MHz 10V/m with 200Hz 50% Pulse 100% AM at 900MHz	
EFT/B Immunity	IEC 61000-4-4 +1kV @ 5kHz on signal ports	
Surge Transient Immunity	IEC 61000-4-5 +1kV line-line (DM) and +2kV line-earth (CM) on signal ports	
Conducted RF Immunity	IEC 61000-4-6 10V rms with 1kHz sine wave 80% AM from 150kHz to 30MHz	

**Specifications – ac (120–240V) Output Module, Cat. No. 1771-OAN**

Emissions	CISPR 11 Group 1, Class A (with appropriate enclosure)	
Enclosure Type Rating	None (open style)	
Keying	Between 16 and 18 Between 22 and 24	
Fuses	Four 4.0A, 250V normal blow fuses (1 per group)	
Field Wiring Arm	Cat. No. 1771-WN	
Field Wiring Arm Screw Torque	7–9 pound-inches (0.7–1.0Nm)	
Conductors	Wire Size	14–22AWG (2.5–0.25mm <sup>2</sup> ) stranded copper wire rated at 60°C or greater 3/64 inch (1.2mm) insulation (max)
	Category	1 <sup>1</sup>
Certifications (when product is marked)	UL CSA CE <sup>2</sup>	UL Listed Industrial Control Equipment CSA Certified Process Control Equipment European Union 89/336/EEC EMC Directive, compliant with: EN 61000–6–4, Industrial Emissions EN 50082–2, Industrial Immunity EN 61326, Meas./Control/Lab., Industrial Requirements EN 61000–6–2, Industrial Immunity European Union 73/23/EEC LVD Directive, compliant with: EN 61131–2, Programmable Controllers C-Tick <sup>2</sup> Australian Radiocommunications Act, compliant with AS/NZS 2064, Industrial Emissions

1 Use this conductor category information for planning conductor routing . Refer to publication 1770-4.1, "Industrial Automation Wiring and Grounding Guidelines."

2 See the Product Certification link at [www.ab.com](http://www.ab.com) for Declarations of Conformity, Certificates, and other certification details.

[www.rockwellautomation.com](http://www.rockwellautomation.com)

#### **Power, Control and Information Solutions Headquarters**

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846